

FETCO® User's Guide and Operator Instructions

CBS-1241 & CBS-1242 Extractor Plus Brewing System FETCO PLUS® Commercial Beverage Equipment



CBS-1242 & CBS-1241 1 gallon Extractor Plus Brewers, shown with 1 gallon L4D dispenser (sold separately)



CONTACT INFORMATION

FETCO® FOOD EQUIPMENT TECHNOLOGIES COMPANY
600 ROSE ROAD
LAKE ZURICH • IL • 60047-0429 • USA
ON THE WEB fetco.coffee



fetco.com

©2020-2021 FOOD EQUIPMENT TECHNOLOGIES COMPANY
PATENTS: <https://www.fetco.com/pl/pages/patents,74.html>

PHONE: (800) 338-2699 (US & CANADA)
(847) 719-3000 (All Countries)
FAX: (847) 719-3001
EMAIL: sales@fetco.com
orders@fetco.com (to order parts and equipment)
techsupport@fetco.com (all service queries)
P212 REV. 000 August 2021

Coffee Brewer: CBS-1240 series

TABLE OF CONTENTS

| | | | |
|---------------------------------------|----|-------------------------------|----|
| Specifications and Requirements | 2 | F Error Codes | 12 |
| SKU Number Identification Key | 2 | G Counters | 13 |
| Enter Programming | 5 | Save & Exit | 14 |
| Programing Menu Layout | 5 | Operator Training | 15 |
| A Program | 7 | Parts Diagram CBS-1241 | 19 |
| B General | 8 | Parts Diagrams CBS-1242 | 21 |
| C Service Inputs | 9 | CBS-1241 Tank Assembly | 23 |
| D Service Outputs | 9 | CBS-1242 Tank Assembly | 25 |
| E Calibration | 10 | Wiring Diagrams | 27 |
| F Service Menu | 11 | | |

Specifications and Requirements

Water Requirements:

CBS-1241 & 1242: 20-75 psig, (138-517kPa) 1½gpm/(5.7lpm)

Water inlet fitting is a 3/8 inch male flare.

Brewer supplied with inlet valve adaptor for BSP to SAE

Brew Volume: Full Batch 1 gallon; (second batch ¾ gallon)

User adjustable from 0.26 gallon to 1-1/4 gallons per brew

Electrical: See electrical configuration chart. 120 Volt; 208-240 Volt; 230 Volt and user configurable

Tank Temperature, as set by factory:

200°F (93°C) inside water tank (at sea level)

Water supply: (Optional) 100-150TDS

All beverage equipment must use filtered water.

Calibrated for 1.0 gal brew/3.75 L & ¾ gallon per brew | Brew Basket 13" X 5" Coffee Filter 13" X 5 or FETCO# F002

Total Brew Cycle—Factory default setting: First batch: 5:30 minutes=[4 minute brew time + 1.30 minute drip delay]

Second batch: 5:00 minutes=[3:30 minute brew time + 1:30 minute drip delay]

Brew-Process parameters are user controllable for:


Brew Volume, Brew Time, Prewet Percent, Prewet Delay, Bypass, and Drip Delay

Weights and Capacities

| Model | Height | Width | Depth | Water tank capacity | Empty Weight | Filled Weight | Shipping Weight | Shipping Dimensions |
|------------------------------------|---------------------|---------------------|---------------------|----------------------|-------------------|--------------------------------------|-------------------|--|
| CBS-1241 Brewer | 34 1/2 in 880 mm | 11 3/4 in 300 mm | 20 3/8 in 520 mm | 4.5 gallon 17 L | 29 lbs 13.2 kg | 55 lbs 25.0 kg | 41 lbs 18.6 kg | 35" x 17" x 22" 88.9 x 43.2 x 55.9 cm |
| CBS-1242 Brewer | 34 1/2 in 880 mm | 19 ¾ in 500 mm | 20 3/8 in 520 mm | 8.5 gallon 32 L | 47 lbs 21.3 kg | 92 lbs 41.7 kg | 58 lbs 26.. kg | 35" x 23" x 25" 88.9 x 58.4 x 63.5 cm |
| Calibrated for 1.0 gal brew/3.75 L | | | | Brew Basket 13" X 5" | | Coffee Filter 13" X 5 or FETCO# F002 | | |

Rough-In Drawings

1201.00060.00 (CBS-1241) 1201.00061.00 (CBS-2142)



| Example: E1241US-1A115-PM001 | | | | | SKU Number Identification Key | | | | | | | | | | |
|------------------------------|----------------|---|----------------------------------|--|-------------------------------|-------|---|-----------------------|--|----------------------|-----------------------------------|---------------|-------------------|--|---|
| Product Line | Level | | Family | Region ID | | Phase | Voltage Range | # Heaters | Individual Heater Wattage | Brew Basket | Hot Water Faucet | Bypass | Brew Basket Locks | Power Cord | |
| E | 1 | 2 | 4 | 1 | U | S | 1 | A | 1 | 5 | P | M | 0 | 0 | 1 |
| E=extractor | 12=PLUS Series | | 41= single side 42= dual side | US =United States IN = International CE = CE NM = NOM | U = 1 or 3 | 1 | A = 100-120 B = 200-240 C = 380-415 D = 440-480 X=120 or 240 Dual Voltage | 1 2 3 4 5 | 1.5 1.7 2.3 3.0 4.0 5.0 | P=plastic M=metal | M=manual A=automatic N=None | 1=Yes 0=no | 1=Yes 0=no | 0=Terminal Block 1= NEMA 5-15P 2=NEMA 5-20P 3=NEMA 6-15P 4=NEMA 6-30P 5= CEE 7/7 Schuko 6=UK1-13P 7= AUSTRALIAN | |

| CBS-1241PLUS Single 1 Gallon-3.0-4.0 Liter Coffee Brewers Domestic models | | | | | | | | |
|---|---------|----------------------|-------|-----|-----------------------|-------|----------|----------------------|
| Electrical and Output Specifications All brewers have factory installed cord and plug 50Hz or 60Hz | | | | | | | | |
| SKU | Voltage | Heater Configuration | Wires | KW | Electrical Connection | Phase | Amp Draw | Brew-Volume per hour |
| E1241US-1A115-PM001 | 120 | 1 X 1.5 kW | 2+G | 1.5 | NEMA 5-15P | 1 | 13.0 | 4.0 gal/15.1 L |
| E1241US-1A123-PM002 | 120 | 1 X 2.3 kW | 2+G | 2.3 | NEMA 5-20P | 1 | 19.7 | 6.1 gal/23.2 L |

| CBS-1241PLUS Single 1 Gallon-3.0-4.0 Liter Coffee Brewers Field configurable Domestic | | | | | | | | |
|--|---------|----------------------|-------|---------|-----------------------|-------|-----------|----------------------|
| Electrical and Output Specifications Brewer has factory installed cord and plug & terminal block 50Hz or 60Hz | | | | | | | | |
| SKU | Voltage | Heater Configuration | Wires | KW | Electrical Connection | Phase | Amp Draw | Brew-Volume per hour |
| E1241US-1X117-PM001 | 120 | 1 X 1.7 kW | 2+G | 1.7 | NEMA 15-5P | 1 | 14.7 | 4.5 gal/17.1 L |
| Domestic-Dual Voltage | 208-240 | 2 X 1.7 kW | 2+G | 2.6-3.4 | Terminal Block | 1 | 12.8-14.7 | 9.0 gal/34.2 L |

| CBS-1241PLUS Single 1 Gallon-3.0-4.0 Liter Coffee Brewers International models | | | | | | | | |
|--|---------|----------------------|-------|---------|-----------------------|-------|-----------|----------------------|
| Electrical and Output Specifications All brewers have terminal block electrical utility connection 50Hz or 60Hz | | | | | | | | |
| SKU | Voltage | Heater Configuration | Wires | KW | Electrical Connection | Phase | Amp Draw | Brew-Volume per hour |
| E1241IN-1B123-PM000 | 200-240 | 1 X 2.3 kW | 2+G | 1.6-2.3 | Terminal Block | 1 | 8.5-10.1 | 6.1 gal/23.2 L |
| E1241IN-1B130-PM000 | 200-240 | 1 X 3.0 kW | 2+G | 2.1-3.0 | Terminal Block | 1 | 10.9-13.0 | 8.0 gal/30.2 L |
| E1241IN-1B130-MM000 | 200-240 | 1 X 3.0 kW | 2+G | 2.1-3.0 | Terminal Block | 1 | 10.9-13.0 | 8.0 gal/30.2 L |
| E1241IN-1B140-PM000 | 200-240 | 1 X 4.0 kW | 2+G | 2.8-4.0 | Terminal Block | 1 | 14.9-17.2 | 10.0 gal/37.9 L |
| E1241NM-1B140-PM000 | 200-240 | 1 X 4.0 kW | 2+G | 2.8-4.0 | Terminal Block | 1 | 14.9-17.2 | 10.0 gal/37.9 L |


| CBS-1241PLUS Single 1 Gallon-3.0-4.0 Liter Coffee Brewers Field configurable International | | | | | | | | |
|--|-------------|----------------------|-------|-----|-----------------------|-------|-----------|----------------------|
| Electrical and Output Specifications Brewer has factory installed cord and plug & terminal block 50Hz or 60Hz | | | | | | | | |
| SKU | Voltage | Heater Configuration | Wires | KW | Electrical Connection | Phase | Amp Draw | Brew-Volume per hour |
| E1241NM-1X123-PM002 | 120 | 1 X 2.3 kW | 2+G | 2.3 | NEMA 5-20P | 1 | 19.7 | 6.1 gal/23.2 L |
| Dual Voltage | 120/208-240 | 2 X 2.3 kW | 3+G | 4.6 | Terminal Block | 1 | 17.1-19.7 | 10.0 gal/37.9 L |

| CBS-1242PLUS Dual 1 Gallon-3.0-4.0 Liter Coffee Brewers Domestic models | | | | | | | | |
|--|---------|----------------------|-------|---------|-----------------------|-------|-----------|----------------------|
| Electrical and Output Specifications All brewers have terminal block electrical utility connection 50Hz or 60Hz | | | | | | | | |
| SKU | Voltage | Heater Configuration | Wires | KW | Electrical Connection | Phase | Amp Draw | Brew-Volume per hour |
| E1242US-1B223-PM000 | 208-240 | 2 X 2.3 kW | 2+G | 3.5-4.6 | Terminal Block | 1 | 17.1-19.7 | 12.2 gal/46.3 L |
| E1242US-1B230-PM000 | 208-240 | 2 X 3.0 kW | 2+G | 4.5-6.0 | Terminal Block | 1 | 22.2-25.5 | 15.9 gal/54 L |
| E1242US-1B230-MM000 | 208-240 | 2 X 3.0 kW | 2+G | 4.5-6.0 | Terminal Block | 1 | 22.2-25.5 | 15.9 gal/54 L |

| CBS-1242PLUS Dual 1 Gallon-3.0-4.0 Liter Coffee Brewers International models | | | | | | | | |
|--|---------|----------------------|-------|---------|-----------------------|-------|-----------|----------------------|
| Electrical and Output Specifications All brewers have terminal block electrical utility connection 50Hz or 60Hz | | | | | | | | |
| SKU | Voltage | Heater Configuration | Wires | KW | Electrical Connection | Phase | Amp Draw | Brew-Volume per hour |
| E1242IN-1B223-PM000 | 200-240 | 2 X 2.3 kW | 2+G | 3.2-4.6 | Terminal Block | 1 | 16.5-19.7 | 12.2 gal/46.3 L |
| E1242IN-1B230-PM000 | 200-240 | 2 X 3.0 kW | 2+G | 4.2-6.0 | Terminal Block | 1 | 21.3-25.5 | 15.9 gal/60.4 L |
| E1242NM-1B230-PM000 | 200-240 | 2 X 3.0 kW | 2+G | 4.2-6.0 | Terminal Block | 1 | 21.3-25.5 | 15.9 gal/60.4 L |


Starting The Brew

FETCO
Ready to Brew



1. Turn the power switch "ON". (Twin Shown)
2. Prepare a brew basket with the correct size filter and appropriate amount of coffee.
3. Slide the brew basket completely into the rails.
4. Place a clean, empty, preheated dispenser under the brew basket.
5. Select a batch & hold the corresponding BREW button in for 1 second to start
6. -STOP button will illuminate,
-Countdown time will display,
-Selected BREW button will flash to indicate brew is in progress.
-All other BREW buttons for that brew head will extinguish.
7. When the brew cycle is finished,
STOP button will extinguish and the BREW button will continue to flash for the amount of time programmed into the DRIP DELAY setting.
This indicates that coffee may still be dripping from the brew basket
For safety- do not remove brew basket until drip-out is complete.

Ready Brewing
5:30



Twin Brewer ready to brew. Example shown: Pressing top right brew position

**Brewing-see #6
above**

Enter Programming

Screens shown are for twin brewer. Single brewer will not have menu A4-A6.

There are seven menu groups-A-G. See the following pages for the batch parameter definitions and all settings for the brewer

TO ENTER PROGRAMMING




- 1-Turn brewer "OFF" from power switch
 - 2-Turn power switch to "ON"
- ...Screen will initialize and then display digital process notifications
- 3-After Initialization-Red "STOP" Lamp turns on
 - 4-Quickly hold down "STOP" button for 5 seconds

When brewer is In PROGRAMMING MODE
-the screen will display:

BATCH PRG!
A (or B-H)

-Illuminated LED indicates active keypad positions

See the following pages for batch parameter definitions and all settings for the brewer



Turn power OFF
Turn power ON
Wait for red LED
And quickly hold down
STOP button on front touch
panel for 5 sec.

First screen will display
for PROGRAMMING-A
Scroll through main menu
topics by pressing "STOP"
button.

Note: Only the left side buttons of a two sided brewer are used for programming

Programing Menu Layout


| A10 to A70 Batch Parameters | | B10-B40 General Settings | | C10-C50 Service Inputs | | D10-D90 Service Outputs | | E10-E70 Calibration | | F10-F120 Service Menu | | G1-G15 Counters | | H10-H11 Exit and Save | |
|--------------------------------|-------------------|-----------------------------|------------------|---------------------------|------------------|----------------------------|------------------|------------------------|----------------------|--------------------------|------------------|--------------------|-------------------|--------------------------|--------------|
| A11 | Brew Volume | B1 | Tank Temperature | C1 | LLC Probe | D1 | Heater SSR | E1 | Ready Temp. Offset | F1 | Firmware Ver. | G1 | Filter Used | H1 | Save Changes |
| A12 | Brew Time | B2 | Brew at Temp | C2 | Basket Sensor | D2 | Fill Valve | E2 | LLC Sensitivity | F2 | Bootloader Ver. | G2 | Filter Life | H2 | EXIT? |
| A13 | Prewet Percent | B5 | Show Tank Temp | C4 | Tank Temperature | D3 | Lt Brew Valve | E3 | Slow Flow Compensate | F3 | Select Model | G3 | Filter Reset | | |
| A14 | Prewet Delay | B4 | Units of Temp | C5 | USB Drive | D4 | Rt Brew Valve | E4 | Lt Brew Flow | F4 | Option Bypass | G4 | Counter Reset | | |
| A16 | Drip Delay | B6 | Units of Volume | C6 | Keyboard Test | D12 | LCD Brightness % | E5 | Rt Brew Flow | F5 | Option BB Lock | G5 | Choose Counter | | |
| A20 | Batch (2) Enabled | B7 | Customer Name | | | D13 | LED Brightness % | | | F8 | Backup to USB | G10 | Brewer Volume [T] | | |
| A21 | Brew Volume | B7 | Customers Name | | | | | | | F9 | Restore from USB | G11 | Brewer Volume | | |
| A22 | Brew Time | B9 | Demo Mode | | | | | | | F10 | Restore Defaults | G12 | LT Brews[T] | | |
| A23 | Prewet Percent | B10 | Eco Mode | | | | | | | F11 | Error Log | G13 | LT Brews | | |
| A26 | Drip Delay | B11 | Eco Idle Time | | | | | | | F12 | Erase Error Log | G14 | Rt Brews [T] | | |
| A30 | Batch (3) Enabled | B12 | Eco Idle Temp | | | | | | | F13 | Service Phone# | G15 | Rt Brews | | |
| A90 | Copy Batch | | | | | | | | | F14 | Override Lt BBS | | See Page 12 | | |
| A91 | Copy Batch: From | | | | | | | | | F15 | Override Rt BBS | | | | |
| A92 | PASTE: To | | | | | | | | | F16 | Override Lt BBL | | | | |
| | | | | | | | | | | F17 | Override Rt BBL | | | | |

Left and Right top and middle batches are permanent SEE BOX on the following page for all "A" menus


The most common programming steps are for the batch volumes and brewing parameters.

The A menus [A1-3 or A1-6] correspond to batch buttons [3 or 6] on the touch panel


Access the A menus to PROGRAM & make changes to individual menu recipes. Menu settings can be copied. Menu positions A1 and A4 [top position] are permanent. Menus A2, A3, A5, A6 can be removed by operator if desired




From A PRG screen
Press button 1 to go to the A menu access screen




From A11 screen
Press **STOP** to scroll to A20.
(A1&A4 are permanent)



From A20 screen
Press STOP to scroll through the remaining (3 or 6) "A" menus. Make any changes as required



From A60 screen
Scroll out to remaining A10-to A70 programming keys. See SAVE & EXIT in previous table



For single and twin
Position of batch buttons

Note: Only the left side buttons of a two sided brewer are used for programming

A Program Menu Features: Batch Parameters

The settings below are shown for the top batch on a single brewer top left button on a twin brewer.
See how to access all A menus on the previous page. Below are the brew settings for default A1 & A2 batches


| POSITION | Program Items | Factory set Default | Programming Range | Increments | Notes |
|--|---|---|------------------------------------|-----------------|---|
| A1.10 | Batch Volume | 1 gal 3.8 L | 0.25 to 1.25 gal 0.95 to 4.75L | 0.01G 0.05L | |
| A1.20 | Brew Time | 4:00 minutes | 2:00 – 12:00 | 0.30 | Default total brew time is 5:30 minutes |
| A1.30 | Prewet Perc. | 0% | 0.00 – 25.0% | 1% | Percentage of total brew volume |
| A1.40 | Prewet Delay (Pause after prewet completes) | 0% [1:00 Min] | [0:10 – 5:00] | 1:00 min | The time between prewetting and start of brew cycle. This feature appears ONLY if Prewet >0:00 |
| A1.60 This is a Safety Feature | Drip Delay | 1:30 mm:ss | 0:30 – 6:00 Min. | | Time that brew basket remains locked during final drip-out →Drip delay remains “ON” for 1:30 minutes if STOP is pressed during brew† |
| A2.00 | BATCH ENABLED | YES (Active) | Middle and Bottom batches A2,3,5,6 | Batch on or off | Batches may be individually enabled, rewritten or deactivated |
| A2.10 | Batch Volume | 0.75gal 2.90L | 0.25 to 1.25 gal 0.95 to 4.75L | 0.01G 0.05L | |
| A2.20 | Brew Time | 3:30 minutes | 2:00 – 12:00 | 0.30 | Default total brew time is 5:30 minutes |
| A2.30 | Prewet Perc. | 0% | 0.00 – 25.0% | 1% | Percentage of total brew volume |
| A2.40 | Prewet Delay (Brew pause after prewet completes) | 0% [1:00 Min] | [0:10 – 5:00] | 1:00 min | The time between prewetting and start of brew cycle. This feature appears ONLY if Prewet >0:00 |
| A2.60 Safety Feature | Drip Delay | 1:30 mm:ss | 0:30 – 6:00 Min. | | Time that brew basket remains locked during final drip-out |
| A30 | Batch Enabled A30 YES - NO + | NO-inactive (defaults to recipe A20 if activated) | Middle and Bottom batches A2,A3 | Batch on or off | Batches may be individually enabled, rewritten or deactivated |
| Batch Copy | Copy From Batch | A90 | A90 1 (1-6) | | |
| | Copy To Batch? | A91 | A91.1 (1-6) | | |

Single Topmost Batch cannot be disabled. TWIN Topmost Batch LEFT & RIGHT cannot be disabled.
Middle and bottom batches may be disabled for single and twin brewer (CBS-1241 and CBS-1242)
† DRIP DELAY will not activate when STOP is pressed within 5 seconds of starting a brew time

RECIPE Location map

Viewing and changing settings for the brew recipes is from the “A” screens with the controls in PROGRAMMING.

The uppermost button positions are permanent and will not display programming step A_0. The table above shows in position A20 that a button position can be made **active or inactive**. Position A1 does not display this step




←DISPLAY→

←STOP→

←BATCH A1→
(permanent)

←BATCH A2→
(enabled by factory)

←BATCH A3→
(disabled by factory)



←DISPLAY

←STOP

←BATCH A4→
(permanent)

←BATCH A5→
(enabled by factory)

←BATCH A6→
(disabled by factory)

| B General Brewer Operation Control Settings, Adjust Brew Flow Rate | | | | | |
|--|------------------------------|--|-------------------------------|----------------|---|
| POSITION | Program Items | Factory set Default | Programming Range | Increments | Notes |
| B1 | Tank Temp. | 200°F-or-93° C NOTE: Equipment is Fahrenheit by default | 77° to 97°C 170°F to 207°F | 0.5°C 1.0°F | Chart to correct for high altitude below |
| B2 | Brew at Temp. | “YES” | ON/OFF | YES/NO | SEE NOTE BELOW |
| B4 | Show Tank Temperature | YES | YES/NO | | To display HW tank temperature on screen |
| B5 | Units of Measure TEMPERATURE | ° Fahrenheit | Fahrenheit/Celsius | C/F | NOTE: Overwrites user settings (see page 9) |
| B6 | Units of Measure VOLUME | Gallons | Gallons/Liter/Ounces | L/Gal/Oz | NOTE: Overwrites user settings (see page 9) |
| B7 | Customer Name | Off | NO or YES | | For name on screen |
| B7 | Customer Name | (only if above is “ON) | Scroll with batch keys | A-Z;a-z;0-9 | 16 characters total |
| B9 | Demo Mode | DEMO ON/OFF | | | Demonstrates the controls for training. Disables all components in demo mode |
| B10 | Eco Mode | On | ON/OFF | YES/NO | If Selected: Lowers hot water tank temperature after preset time of inactivity |
| B11 | Eco Idle Time | 1Hr | 1-6 hours | 1 hour | Time of inactivity to go into ECO Mode |
| B12 | Eco Idle Temp | 170°F | 158-176°F | 1 degree | Temperature that hot water tank is lowered to when in ECO Mode |
| B13 | Filter Life | OFF | ON/OFF | YES/NO | Water filter life is accessed in G-Counters. This is user set and will display indicator to change water filter |

BREW AT TEMPERATURE DEFINITIONS

| | | |
|---|--|--|
| DEFAULT: BREW AT TEMP: “ON” | | |
| <p>(FACTORY DEFAULT FOR BREWER)</p> <p>“BREW at TEMP:</p> <p>-Batch will not start if tank temperature is below set point.</p> <p>-Display will show “HEATING” and hot water tank temperature</p> <p>The “BREW START” entry buttons will not illuminate until the hot water tank reaches the selected temperature.</p> <p>Controls allow both sides of dual brewer to operate if one side has an ongoing brew started and the second side brew is selected.</p> <p>Notifications shown on screen:</p> <p>TEXT: HEATING→Tank above 87°C/189°F-will allow brew at low temperature.</p> <p>Coffee flavor may be affected</p> <p>TEXT: L. HEAT→Tank above 76°C/169°F-will allow brew at low temperature.</p> <p>Coffee flavor will be noticeably affected</p> | <p>Hot water tank not at brew temp setpoint.</p> <p>Tank temp→</p> <p>STOP is not lit → BREW START buttons not lit. and are disabled.</p> <p>When hot water tank temperature is at setpoint. Buttons will illuminate and “READY” will be displayed</p> | |
| | <p>USER SELECTABLE OPTION: BREW AT TEMP: OFF</p> <p>(Not recommended) Unit will operate at cold temperature</p> <p>Allows brewing at any temperature above 77°C/170°F</p> <p>Below 70°C/170°F The red colored ready lights switch turn off</p> | |

| [ft] | [m] | Suggested Setting[°F] | Boiling point[°F] | Suggested Setting[°C] | Boiling point [°C] |
|------|------|-----------------------|-------------------|-----------------------|--------------------|
| 0 | 0 | 205 | 212.0 | 96 | 100.0 |
| 500 | 152 | 205 | 211.0 | 96 | 99.5 |
| 1000 | 305 | 200 | 210.1 | 93 | 98.9 |
| 2000 | 610 | 200 | 208.1 | 93 | 97.8 |
| 2500 | 762 | 200 | 207.2 | 93 | 97.3 |
| 3000 | 914 | 200 | 206.2 | 93 | 96.8 |
| 3500 | 1067 | 197 | 205.3 | 92 | 96.3 |
| 4000 | 1219 | 195 | 204.3 | 91 | 95.7 |
| 4500 | 1372 | 194 | 203.4 | 90 | 95.2 |
| 5000 | 1524 | 194 | 202.4 | 90 | 94.7 |
| 5500 | 1676 | 193 | 201.5 | 89 | 94.2 |
| 6000 | 1829 | 192 | 200.6 | 89 | 93.6 |
| 6500 | 1981 | 191 | 199.6 | 88 | 93.1 |
| 7000 | 2134 | 190 | 198.7 | 87 | 92.6 |
| 7500 | 2286 | 188 | 197.8 | 86 | 92.1 |
| 8000 | 2438 | 187 | 196.9 | 86 | 91.6 |
| 8500 | 2591 | 185 | 196.0 | 85 | 91.1 |

| C Service Inputs | | Brewer Sensors and Keypad | | | |
|------------------|----------------------|---------------------------|---|-------------------------|---------------------------------------|
| POSITION | Program Items | Factory set Default | Programming Range | Increments | Notes |
| C1 | LLC Probe continuity | Direct read | Reading of tank water resistance in TDS | ≈850- LOW ≈1600-HIGH | Nominal values |
| C2 | Brew Basket Sensor | L-YES R-YES | YES or NO | | |
| C4 | Tank Temperature | Direct read | Hot water tank temperature | | Actual values |
| C5 | USB Drive | NO | (not in use) | | |
| C6 | Keyboard Test | Calibrate | Checks buttons under membrane cover | YES/NO | Follow directions on the touch screen |

| D Service Outputs | | Test Valves and Heaters; Set screen brightness | | | |
|---|----------------------------------|--|--------------------------------------|----------------------|---|
| POSITION | Program Items | Factory set Default | Programming Range | Increments | Notes |
| D1 | Heater SSR Test | Press button 2 to test (button 1 stops test) | Activates heater Default is 10 sec.. | Toggle +/- OFF or ON | Energizes Heater(s) WARNING! Service use only. |
| D2 | Fill Valve Test | Press button 2 to test (button 1 stops test) | Activates valve Default is 10 sec. | Toggle +/- OFF or ON | Press To Test |
| D3 | Lt (left) Brew Valve Test | (Press to test) | Activates valve Default is 10 sec. | Toggle +/- OFF or ON | Runs valve to verify flow. NOTE: Have container under brew basket. |
| D4 | Rt (right) Brew Valve Test | (Press to test) | Activates valve Default is 10 sec. | Toggle +/- OFF or ON | Runs valve to verify flow. NOTE: Have container under brew basket. |
| D5* | Lt (left) Bypass Valve Test | (Press to test) | Activates valve Default is 10 sec. | Toggle +/- OFF or ON | Runs valve to verify flow. NOTE: Have container under brew basket. |
| D6* | Rt (right) Bypass Valve Test | (Press to test) | Activates valve Default is 10 sec. | Toggle +/- OFF or ON | Runs valve to verify flow. NOTE: Have container under brew basket. |
| D7* | LT (left) Brew Basket Lock Test | (Press to test) | Activates Brew Basket Lock | Toggle +/- OFF or ON | Press To Test |
| D8* | RT (right) Brew Basket Lock Test | (Press to test) | Activates Brew Basket Lock | Toggle +/- OFF or ON | Press To Test |
| *Active if bypass and brew basket lock is installed and activated on equipment. Bypass must be installed and is activated in F4-SERVICE MENU, Brew basket lock is located in F5 Single series displays right side only Left Valve display is only for twin side brewer. | | | | | |
| D12 | LCD Brightness | Brightness=90% | 20-100% | 5% | Adjust LCD screen brightness only-Not for LEDs under buttons |
| D13 | LED Brightness | Brightness=60% | 20-100% | 5% | Adjust LED button brightness only-Not for the screen display LCD |

| E Calibration | | Brewer Sensors and Keypad | | | |
|---------------|----------------------------|--|---|-------------------------|--|
| POSITION | Program Items | Factory set Default | Programming Range | Increments | Notes |
| E1 | Ready Temp. Offset | -4°F -2°C | -2° to -9°F -1° to -5° C | 1°F 1°C | Compensates output to measured temperature |
| E2 | LLC Sensitivity | NORMAL ("NORMAL" for most water) | HIGH (Biased for reverse osmosis water or very pure water) | NORMAL HIGH | Liquid level control sensitivity. High, 1300Ω is for reverse osmosis water or very pure water. |
| E3 | Slow flow rate from supply | ON | OFF/ON | Toggle +/- YES or NO | Trims fill system for low supply or Flojet use |
| E4 | LT Brew valve flow rate: | 0.50 gallon/minute (1.85 liter/minute) (64 ounces/minute) | 0.42-0.58 Gallons 1.55-2.20 Liters 53-74 fl.ounces | 0.01G 0.05L 1 oz. | Adjusts flow rate |
| E5 | RT Brew valve flow rate: | 0.50 gallon/minute (1.85 liter/minute) (64 ounces/minute) | 0.42-0.58 Gallons 1.55-2.20 Liters 53-74 fl.ounces | 0.01G 0.05L 1 oz. | Adjusts flow rate |
| E6* | LT Bypass valve flow rate: | 0.37 gallon/minute (1.60 liters/minute) (47 ounces/minute) | 0.30-0.43G 1.10-1.65Liter 38-56 fl.ounces | 0.01G 0.05L 1 oz. | Adjusts flow rate |
| E7* | RT Bypass valve flow rate: | 0.37 gallon/minute (1.60 liters/minute) (47 ounces/minute) | 0.30-0.43G 1.10-1.65Liter 38-56 fl.ounces | 0.01G 0.05L 1 oz. | Adjusts flow rate |

*Active if bypass is installed and activated on equipment

Use this formula to compensate for minor discrepancies in actual volume versus programmed volume.

See "PROGRAM" [E4](#) & [E5](#) For valve settings and calibration. Factory set brew valve flow rates are in liter/min

Default Brew Valve Flow Rate—CBS-1240 Brewers


| <u>CBS-1240</u> | <u>Gal/minute</u> | <u>Range</u> |
|--------------------------------|-------------------|----------------|
| Right and Left Brew Valve FR | 0.50 | 0.42g to 0.58g |
| Right and Left Bypass Valve FR | 0.37 | 0.30g to 0.43g |

Set FR **lower** to **increase** volume,
Set FR **higher** to **decrease** volume

$$\frac{\text{ACTUAL VOLUME}}{\text{PROGRAMMED VOLUME}} \times \text{CURRENT SETTING} = \text{NEW SETTING}$$

Use the formula above to determine the correct setting

| F Service Menu | | Software & Code View and Settings | | | |
|--|--------------------|--------------------------------------|--|--|---|
| POSITION | Program Items | Factory set Default | Programming Range | Increments | Notes |
| F1 | Display Firmware | 2.1.210504 | | | Displays current version [6/2020] |
| F2 | Display Bootloader | 2.0.210317 | | | Displays current version [6/2020] |
| F3 | Select Model | CBS-1241 or 1242 Will need reboot | Scroll to brewer model Save & Exit | CBS-1221 CBS-1241, CBS-1242 CBS-1241, CBS-1242 CBS-1251, CBS-1252 CBS-1261, CBS-1262 MBS-1241, MBS-1251 | NOTE: Overwrites all user settings (See below) |
| F4 | Option Bypass | Yes | NO or YES | | Turns on bypass |
| F5 | Option BB Lock | NO | NO or YES | | Apply to future upgrade kit |
| F8 | Backup to USB | NO | Follow prompts | Saves settings | Insert blank USB |
| F9 | Restore From USB | | Applies settings from USB | | Insert USB Will need reboot |
| F10 | Restore Defaults | NO | NO/YES | | Reset to factory |
| When selecting F10-RESTORE DEFAULTS, save and exit programming (page 13). Brewer returns to factory defaults for your model and deletes all user inputted changes. | | | | | |
| F11 | Error Log | Lists up to six codes, in order | 1: ; 2: ;3:;4: ;5: ;6: 1=Newest/6=Oldest LAST six errors only | Newest=first Oldest=last | See Error Code Chart for references |
| F12 | Erase Error Log | NO + | | Toggle +/- YES or NO | FACTORY USE ONLY. DO NOT RESET |
| F13 | Service Phone # | | | | Set phone for display |
| F14 | Override Lt BBS | NO | NO/YES | Toggle +/- YES or NO | Disables brew basket sensor (CBS-1242 only) |
| F15 | Override Rt BBS | NO | NO/YES | Toggle +/- YES or NO | Disables brew basket sensor |
| F16 | Override Lt BBL | NO | NO/YES | Toggle +/- YES or NO | Disables brew basket lock (CBS-1242 only) |
| F17 | Override Rt BBL | NO | NO/YES | Toggle +/- YES or NO | Disables brew basket lock |

| F Error Codes | | | |
|--|---|--|--|
| DO NOT CLEAR ERROR CODES UNTIL ERROR IS IDENTIFIED AND CORRECTED | | | |
| →Contact factory or specialized personnel for error codes | | | |
| Code | Description | Possible Cause | Corrective Action |
| 001 | Software error-error on start up or corrupted software | Improper start-up or shutdown | Restart , if still fault: reload software |
| 002 | Internal flash corrupted internal data memory malfunction | Error found in cyclic redundancy check CRC | Restart , if still fault: reload software If not corrected :replace board |
| 050 | Short-circuit in temperature probe | Probe failure. | Replace probe. |
| 051 | Open temperature probe. | Bad probe connection, or probe failure. | Check all connections. Replace probe if necessary. |
| 100 | Initial Fill Error. Initial fill time took longer than expected after powering up. | Water supply flow rate is too low. | Watch for short potting during brew cycle. Investigate cause of low flow rate. (Clogged water filter...) |
| 101 | Error on refill-. Tank did not refill within expected time. | Water supply flow rate is too low. | Watch for short potting during brew cycle. Investigate cause of low flow rate. (Clogged water filter...) |
| 200 | Heating flatline-Tank is boiling | Heater is on, temperature is not rising/dropping | High elevation correction. Bad heaters or temperature probe or position |
| 201 | Heater open, high limit thermostat, or Solid State Relay (SSR) fault | Failure of heating element, SSR, high limit | Check and replace heating elements, SSRs, high limit devices if necessary. |
| 202 | Heater Shorted or Stuck SSR | Heater is off and heating SSR is stuck "ON" | Check ohms on heater (15-60Ω). SSR may be stuck in ON mode-replace SSR. |
| 255 | Keyboard [HID] error | Usually from longer than 10 se contact. Or faulty reassembly after service | Restart , if still fault: reload software. If mechanical: replace module |
| NO BSKT <u>Insert Brew Basket</u> |  | Brew basket must be in place This is a SAFETY FEATURE | Insert brew basket into brewer rails to enable brewer |

G Counters Brewer Usage, Water Filter Usage, and Statistics

ROLE: [LT]=Permanent total for lifetime of ma[chine R]=operator resettable [User]=Input needed from operator


| Position | Counter | Program items | Role | Information | Increments | Notes |
|---|----------------|------------------|--------|---|--|---|
| G1-G3 are for water filter maintenance. Filter Life readings (G1, G2, G3) must be activated in B13 GENERAL if they are not visible and the equipment has a water filter. All beverage equipment must use filtered water and filter cartridges must be monitored for quality | | | | | | |
| G1 | A, S, B | Filter Used | [User] | 0G | Gallons/Liters | Amount of water passed through external water filter. For filter life |
| G2 | A, S, B | Filter Life | [User] | 2,625Gal 10,000Liters | 25 gal 100 L | Upload published life of filter |
| G3 | A, S, B | Filter Reset | [User] | NO | Toggle +/- ,Y or N | Reset when replacing external water filter |
| G4 | A, S, B | Counter Reset | [User] | NO | Toggle +/- ,Y or N | Resets all resettable counters to zero |
| G5 | A, S, B | Choose Counter | | Factory set to BASIC | Basic= B Advanced= A Statistical= S | Stored brewer component activity. See column 2, Counters , to identify where counters are located. |
| G10-G15 Number of brews and volumes handled. Available in BASIC counter only (G5) | | | | | | |
| G10 | B | Brewer Volume | [LT] | Dispensed volume | Gallons/Liters | Total of brews and hot water dispensed |
| G11 | B | Brewer Volume | [R] | | | |
| G12 | B | Lt Brews | [LT] | Left side brew total CBS-1242 | Count | Total brews-Left side (CBS-1242 only) |
| G13 | B | Lt Brews | [R] | | | |
| G14 | B | Rt Brews | [LT] | Right side brew total CBS-1241&CBS-1242 | Count | Total brews-Right side CBS-1241&CBS-1242 |
| G15 | B | Rt Brews | [R] | | | |
| G20-G55 component use cycles and volumes handled. Available in ADVANCED counter only (G5) | | | | | | |
| G20 | A | Fill Cycles | [LT] | Hot water tank refill cycles | Count | Cycles of hot water tank refill |
| G21 | A | Fill Cycles | [R] | | | |
| G22 | A | Fill Volume | [LT] | Total volume of water for all brews | Gallons/Liters | Quantity of water for brews |
| G23 | A | Fill Volume | [R] | | | |
| G24 | A | Lt Brew Cycles | [LT] | Left brew valve operation on/off | Count | Totalized cycles of valve operation (CBS-1242 only) |
| G25 | A | Lt Brew Cycles | [R] | | | |
| G26 | A | Lt Brew Volume | [LT] | Left brew valve flow through volume | Gallons/Liters | Totalized volume through left valve (CBS-1242 only) |
| G27 | A | Lt Brew Volume | [R] | | | |
| G28 | A | Rt Brew Cycles | [LT] | Right brew valve operation on/off | Count | Totalized cycles of valve operation CBS-1241&CBS-1242 |
| G29 | A | Rt Brew Cycles | [R] | | | |
| G30 | A | Rt Brew Volume | [LT] | Right brew valve flow through volume | Gallons/Liters | Totalized volume through right valve CBS-1241&CBS-1242 |
| G31 | A | Rt Brew Volume | [R] | | | |
| G32 | A | Lt Bypass Cycles | [LT] | Left bypass valve operation on/off | Count | Totalized cycles of valve operation (CBS-1242 only) |
| G33 | A | Lt Bypass Cycles | [R] | | | |
| G34 | A | Lt Bypass Volume | [LT] | Left bypass valve flow through volume | Gallons/Liters | Totalized volume through left valve (CBS-1242 only) |
| G35 | A | Lt Bypass Volume | [R] | | | |
| G36 | A | Rt Bypass Cycles | [LT] | Count | Count | Totalized cycles of valve operation CBS-1241&CBS-1242 |
| G37 | A | Rt Bypass Cycles | [R] | | | |
| G38 | A | Rt Bypass Volume | [LT] | Right bypass valve flow through volume | Gallons/Liters | Totalized volume through right valve CBS-1241&CBS-1242 |
| G39 | A | Rt Bypass Volume | [R] | | | |
| G48 | A | Lt BBL Cycles | [LT] | Left brew basket lock flow through volume | Count | Totalized cycles of brew basket lock operation (CBS-1242 only) |
| G49 | A | Lt BBL Cycles | [R] | | | |
| G50 | A | Rt BBL Cycles | [LT] | Right brew basket lock operation on/off | Count | Totalized cycles of brew basket lock operation CBS-1241&CBS-1242 |
| G51 | A | Rt BBL Cycles | [R] | | | |
| G52 | A | Heater Cycles | [LT] | ON/OFF switching for heating elements | Count | Totalized cycles of heater switching |
| G53 | A | Heater Cycles | [R] | | | |
| G54 | A | Heater On Time | [LT] | Total ON time for heating element | Hour | Totalized heater ON time in hours |
| G55 | A | Heater On Time | [R] | | | |
| G80-G91 See illustration below for batch button positions Available in STATISTICAL counter only (G5) | | | | | | |
| G80 | S | Batch 10 Cycles | [LT] | Menu button selection and activation count | Count | Total brews-left side top button (CBS-1242 only) |
| G81 | S | Batch 10 Cycles | [R] | | | |
| G82 | S | Batch 20 Cycles | [LT] | Menu button selection and activation count | Count | Total brews-left side middle button (CBS-1242 only) |
| G83 | S | Batch 20 Cycles | [R] | | | |
| G84 | S | Batch 30 Cycles | [LT] | Menu button selection and activation count | Count | Total brews-left side bottom button (CBS-1242 only) |
| G85 | S | Batch 30 Cycles | [R] | | | |
| G86 | S | Batch 40 Cycles | [LT] | Menu button selection and activation count | Count | Total brews-right side top button CBS-1241&CBS-1242 |
| G87 | S | Batch 40 Cycles | [R] | | | |
| G88 | S | Batch 50 Cycles | [LT] | Menu button selection and activation count | Count | Total brews-right side middle button CBS-1241&CBS-1242 |
| G89 | S | Batch 50 Cycles | [R] | | | |
| G90 | S | Batch 60 Cycles | [LT] | Menu button selection and activation count | Count | Total brews-right side bottom button CBS-1241&CBS-1242 |
| G91 | S | Batch 60 Cycles | [R] | | | |

[LT] denotes LifeTime or non-resettable counter [R] denotes a user resettable counter


The brewer will save changes only from the "H" menu. **DO NOT** reboot brewer or toggle ON/OFF-exit as below.

TO EXIT PROGRAMMING & HOW TO SAVE CONTROL SETTING CHANGES


HOW TO SAVE CHANGES AND EXIT-*The brewer is in PROGRAMMING mode.*




From any screen-
Press STOP button until the EXIT ("H") screen appears




From the "H" screen
Press button **2** to toggle to the EXIT-**YES** screen



From EXIT screen
Press button **1** to toggle to the SAVE screen



From SAVE screen
Press button **2**, to toggle to the SAVE-**YES** screen



To SAVE and EXIT
Press button **1** to SAVE your changes and EXIT

Note: Only the left side buttons of a two sided brewer are used for programming

NOTE: User Settings will be erased and overwritten to factory default settings by the following five programming changes

- 1) When setting or changing units of display for the tank temperature (F Fahrenheit or C Celsius). **(SETTING B4)**
- 2) When setting or changing units of display for the volume (L, G gallons). **(SETTING B5)**
- 3) When setting brewer model →The software sets equipment to brewer defaults **(SETTING F3)**
- 4) When loading from USB (Reprograms settings) **(SETTING F9)**
- 5) When restoring defaults (Reloads to defaults) **(SETTING E10)**

Operator Training

Review the operating procedures with whoever will be using the brewer.

Pay particular attention to the following areas:

1. Always pre-heat the dispensers before the first use of each day by filling them halfway with hot water and letting them stand for at least 5 minutes.
2. Do not remove the brew basket from a coffee brewer until it has stopped dripping.
3. Make sure the dispenser is empty before brewing into it.
4. Show how to attach covers, close, and or secure the dispensers for transporting.
5. Show the location and operation of the water shut off valve as well as the circuit breaker for the brewer.
6. Steam from the tank will form condensation in the vent tubes. This condensation will drip into and then out of the brew baskets. Up to 1/4 cup/118cc discharging overnight is possible. Place an appropriate container under each brew basket when not in use.
7. We recommend leaving the power to the brewer on overnight. The water tank is well insulated and very little electricity is used to keep the tank hot. Leaving the brewer in the "ON" position will also avoid delays at the beginning of shifts for the brewer to reach operating temperature.


Cleaning & Maintenance

After Each Brew:

1. Dispose of grounds and rinse brew basket.
2. Never strike a brew basket or hit it against a hard surface.
This will damage the brew cone, and may damage the brew basket support rails
3. Rinse dispensers before reuse.

Every Day:

1. Wash brew basket with hot sudsy water.
2. Pull CSD from the spray head, it is magnetically attached. Use gloves or a heavy towel. → Wash off any film and reattach. Use vinegar if limescale filming is present.
3. Clean dispensers with hot suds water and a brush, rinse and air dry.
4. Use only a soft cloth and hot suds on the outside to avoid scratches. Never use abrasives that will scratch surface.



Weekly

1. Use a commercial coffee dispenser cleaner such as URNEX™, TABZ™, DIP-IT™ or Squeak 'n Clean™.
2. Carefully Follow the instructions supplied with the cleaning product
3. Never use spray cleaners, solvent, solvent based cleaner or petroleum based polish anywhere on dispensers

Warning

1. Turn off power before any cleaning procedure, including wiping the exterior for appearance reasons.
2. Dry the exterior, especially the face panel, before turning on power.
3. Do not apply any type of spray cleaner on the face panel of this equipment.
4. Never use solvent or solvent-based cleaner or petroleum based polish anywhere on this equipment.
5. Dry the face of the touch pad before turning on power
6. Do not electrically energize this equipment or attempt operation without all covers in place and all screws fastened.
7. Unplug machine before disassembly or servicing.

Safety Notes

1. Professional installation is required. This appliance is manufactured only for commercial use
2. Operational requirements and maintenance for commercial cooking appliances differ from household appliances.
3. Operators must be trained for this equipment and must understand the use, maintenance and hazards.
4. Access to the service area is restricted to persons having safety/hygiene knowledge and practical experience of the coffee brewer. This appliance must be installed in locations where it can be overseen by adult trained personnel.
5. Do not attempt to move hot beverage equipment once it is filled. Drain equipment before moving.
6. FETCO commercial coffee brewers prepare large amounts of coffee or tea in a single batch using very hot water
7. Commercial coffee brewers provide very hot water from the spray head, brew basket and faucet when it is pulled.
8. Coffee brewers may continue to dispense very hot water from the mechanically operated faucet after the electronic touchpad is completely disabled by turning off the power switch on the lower back of the unit or unplugging the unit.
9. For safety, the brewer control locks the brew basket for 6.0 minutes after starting the brew.
10. Never attempt to defeat the factory set (default) time that the brew basket is locked for safety from start of brew.

Keep these instructions for training and future reference.

General:

1. If not installed correctly by qualified personnel, the brewer will not operate properly, and damage may result.
 2. Utilize only qualified beverage equipment service technicians for service and installation.
 3. Always have an empty dispenser under spray head of all coffee brewing equipment-including when at idle
 4. Damages resulting from improper installation are not covered by the warranty and will void the warranty.
- Below are the key points to consider before installation:

Electrical:

1. All CBS_Series brewers require **an electrical ground wire**. Installation without grounding is dangerous.
2. Note Equipotentiality Terminal, if present, (To identify the terminals which, when connected together, bring the various parts of equipment or of a system to the same potential, not necessarily being the earth (ground) potential, e.g. for local bonding.)
3. Verify voltages, polarity, circuits, and circuit breaker access before attaching equipment.
4. Brewers in this series wire differently in regard to a neutral wire. Review the wire diagrams.
5. The electrical diagram is located in the User's Guide and online at www.fetco.com.
6. Make sure of the tight grounding of the equipment and use the external ground bolt.
7. The installation must comply with applicable federal, state, and local codes having jurisdiction at your location. Check with your local inspectors to determine what codes will apply.

→See wiring diagrams on pages 24 to 26 for connections



Plumbing:

1. North America: All installations must comply with applicable federal, state, or local plumbing codes.
2. All Others: The water and waste piping and connections shall comply with the International Plumbing Code, International Code Council (ICC), or to the Uniform Plumbing Code (UPC).
3. Install a backflow prevention device. Most municipalities require a recognized backflow preventer
Usable on all hot beverage and cold beverage equipment is a WATTS® SD-2 or SD-3.
WATTS spring loaded double check valve models are accepted by most zoning authorities.
→The check valve should be as close to the water supply inlet of the beverage equipment as possible
4. All beverage equipment must use a water filter. A finishing carbon filter is preferred
5. Install the filter unit after a water shutoff valve and in a position to facilitate filter replacement.
6. The water line and water filter must be flushed thoroughly prior to connecting it to the brewer to prevent debris from contaminating the machine, and flushed again with each replacement filter installed
7. Verify that the water line will provide a flow rate of at least 1½gpm/(5.7lpm) per minute and the water pressure is between 20-75 psig (138-517kPa) before making any connections
8. Only use the supplied factory fitting to attach water supply line to brewer (shipped in brew basket)
9. The supplied fitting is a 3/8" flare/compression fitting for 1/4" supply line. Other adaptors may be substituted.
10. Hand tighten the factory fitting when connecting the stub on the brewer. This will reduce stress on the internal connections and reduce the possibility of leaks developing after the install has been completed

Tank Drain

The water tank must be drained before maintenance procedures, and when the unit is to be relocated or shipped. Drain is for service use only and must not be permanently connected. NOTE: Never plumb a water line to the drain.


1. Disconnect power and water to unit. DANGER: Ensure that all utility connections to the brewer are broken.
2. Move the unit near a sink or obtain a container large enough to hold four gallons of water.
→Note: The hot water tank may hold up to 4.5 gallons (CBS-1241 8.5 gal CBS-1242).
3. Remove the front panel and tank cover and allow the tank to cool to a safe temperature
4. The tank drain line and clamp are located inside-under the hot water tank. Pinch the drain line clamp to close
5. Locate the fill valve against the back wall, using pliers, loosen the hose clamp and move it back over the tube.
→Note Do not loosen the hose clamp to the bottom of the hot water tank
6. Crimp the tube an inch or two away from the drain plug to prevent water from flowing and pull it off the valve.
7. Pull the tube end out of the brewer and position over sink or bucket.
8. Release the crimped tube and hose clamp and allow the water to flow into the sink or container.
9. Reverse steps 4-8 when service is complete. Ensure pinch clamp is open and hose clamps are in place.

| Brewer | Hot Water Tank Capacity | OPEN Leave open for use |  |
|-----------------|-------------------------|--|---|
| CBS-1241 Single | 4.5 gal 17 liter | PINCH SHUT To drain tank & service brewer |  |
| CBS-1242 Twin | 8.5 gal 32 liter | | |

Installation safety and hygiene directions-For International and CE equipment

1. Access to the service area is restricted to persons having safety/hygiene knowledge and practical experience of the coffee brewer. This appliance must be installed in locations where it can be overseen by trained personnel.
2. For proper operation, this appliance must be installed indoors where the temperature is between 10°C/50°F to 35°C/95°F. Drain and remove all liquid from equipment and lines if exposed to freezing temperatures.
3. All commercial cooking equipment, including this unit, is not intended for use by children or persons with reduced physical, sensory, or mental capabilities. Ensure proper supervision of children and keep them away from the unit.
4. Children should be supervised to ensure that they do not play hot beverage equipment.
5. This unit must be installed and serviced by qualified personnel only.
6. Installation must conform to all local electrical and plumbing codes. Installation by unqualified personnel will void the unit warranty and may lead to electric shock or burn, as well as damage to unit and/or its surroundings.
7. If the power cord requires repair or replacement-it must be performed by the manufacturer or authorized service personnel with the specified cord only from the manufacturer in order to avoid a hazard.
8. Review the dimensions for the unit and verify that it will fit properly in the space intended for it. Verify that the counter or table will support the total weight of the brewer and dispensers when filled (See: Technical Data).
9. Place the brewer on the counter or stand. When the brewer is in position, level it front to back as well as side-to-side by adjusting the legs.
10. Brewers will need a sturdy supported surface for operation. Do not move brewers when filled.
11. Do not tilt appliance more than 10° to insure safe operation.
12. Unit is for protected indoor use only. Do not steam clean or use excessive water on unit.
13. This unit is not “jet-proof” construction. Do not pressure wash or use jet spray to clean this unit.
14. The unit is not waterproof-do not submerge or saturate with water.

**Equipment exposed to flood and contaminated must not be used due to electrical and food safety.
Do not operate if unit has been submerged or saturated with water.**



WARNING

All electrical connections must be in accordance with local electrical codes and any other applicable codes. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard.

To prevent an electric shock hazard this device must be bonded to equipment in close proximity with an equipotential bonding conductor. This device is equipped with a bonding lug for this purpose and is marked with the following symbol




| | | |
|---------------|----------------|---|
| | WARNING | To reduce risk of electric shock or fire. |
| | | FETCO® Hot Beverage Equipment is for commercial use only. |
| | | Do not remove or open cover. No user serviceable parts inside. Refer installation and service to qualified personnel. |
| | | Caution, disconnect from power supply before servicing. |
| | | GROUND: National Electrical Code requires separate grounding wire. |
| | | Use dedicated circuit with capacity rated by local code or National Electrical Code for the current draw of this equipment. Check serial number plate on right side for power requirements. |
| | | Locate unit away from source of heat. Do not install or use near combustibles. |
| | | THIS APPLIANCE IS ENERGIZED WHENEVER IT IS CONNECTED TO A POWER SOURCE |
| | | FAILURE TO COMPLY RISKS EQUIPMENT DAMAGE, PROPERTY DAMAGE, FIRE, OR SHOCK HAZARD |
| Notice | | This equipment must be installed with a backflow protection device to comply with federal, state or local municipality codes. |
| Notice | | Read the user guide before installing and operating this unit. |


Labels and warnings for hot beverage equipment

For BACK PANEL of equipment (1046.00035.00)



Brew Baskets

| Plastic Brew Basket | |
|--|---|
| Part Number B014218BN2BK – Complete Plastic Brew Basket | CBS-1241 & CBS-1242 |
|  <p>Brew basket handle plug for polymeric brew baskets is available in optional colors.</p> | Part Number Plug Insert color |
| | 1023.00195.00 BROWN PLUG, BB HANDLE |
| | 1023.00194.00 BLACK PLUG, BB HANDLE |
| | 1023.00190.00 RED PLUG, BB HANDLE |
| | 1023.00191.00 GREEN PLUG, BB HANDLE |
| | 1023.00192.00 ORANGE PLUG, BB HANDLE |
| | 1023.00180.00 BLUE PLUG, BB HANDLE |

| Stainless Steel Brew Basket | | | |
|-----------------------------|-----|-------------------------|--|
| Ref# | Qty | Part Number | Description |
| | | B003218B1 | Complete Stainless Steel Brew Basket |
| 1 | 1 | 1112.00128.00 | BB WELDMENT 13" X 5", .218 DIA HOLE |
| 2 | 1 | 1046.00025.00 | BREW BASKET WARNING LABEL |
| 3 | 1 | 1082.00040.00 | SCREW, 1/4-20 X .5, FL HD, PH., W/NYLON |
| 4 | 1 | 1009.00006.00 | WIRE BASKET |
| 5 | 1 | 1102.00064.00 | HANDLE W/MAGNET ASY, BLACK |
| | | Optional colored handle | 1102.00065.00 HANDLE W/MAGNET ASY, RED |
| | | Optional colored handle | 1102.00066.00 HANDLE W/MAGNET ASY, GREEN |
| | | Optional colored handle | 1102.00067.00 HANDLE W/MAGNET ASY, ORANGE |



Parts Diagram CBS-1241






FETCO CBS-1241
 Drawing Number
 1101.00580.00

| Ref | Qty | Part Number | Description Drawing 1101.00580.00, CBS-1241 |
|-------|-----|---------------|---|
| 1 | 1 | 1111.00104.00 | WELDMENT BODY, CBS-2241 |
| 2 | 6 | 1084.00051.00 | NUT, HEX LOCKWASHER, #8-32, 18-8 ST. STL. |
| 3 | 1 | 1102.00480.00 | FRONT PANEL ASSY, SINGLE, PLUS SERIES |
| 4 | 2 | 1082.00029.00 | SCREW, #6 X 3/8 LG, TRUSS HD PHIL, SHEET MTL |
| 5 | 2 | 1082.00058.00 | SCREW, # 8-32 X 5/8, FLAT HD, PH, 18-8 SS |
| 6 | 1 | 1102.00471.00 | ELECTRICAL COMPONENT LATTICE, NEXT GEN XV+ |
| 6 REF | 1 | Reference | ELECTRICAL COMPONENT LATTICE, NEXT GEN XV+ |
| 6-1 | 1 | 1023.00350.00 | ELECTRICAL MOUNTING LATTICE, COMMON |
| 6-2 | 1 | 1052.00023.00 | EUROSTRIP HE16 TERM. BLOCK, 4 POLE, 63 AMP, 18-8 AWG |
| 6-3 | 2 | 1082.00056.00 | SCREW, # 8-16 x 1" PAN HD PHIL, THREAD FORMING, FOR PLASTICS, 18-8 SS |
| 6-4 | 2 | 1058.00024.00 | SWITCH, POWER, DOUBLE POLE, 16A, 125/250 VAC |
| 6-5 | 4 | 1057.00043.00 | SOLENOID VALVE, 5.5L/min, 180 DEG, 24VDC |
| 6-6 | 2 | 1082.00010.00 | SCREW, PAN HD. PHIL. MACH., M4x10 ZINC-PLATED |
| 6-7 | 1 | 1052.00059.00 | POWER SUPPLY, 90-264VAC/24VDC, 2.25A |
| 6-8 | 2 | 1082.00020.00 | SCREW, #6 X 5/8, TRUSS HD PHIL, SHEET MTL |
| 6-9 | 2 | 1058.00055.00 | USB CONNECTOR |
| 7 | 1 | 1097.00171.00 | ADHESIVE, RGB LED BAR |
| 8 | 1 | 1023.00390.00 | LENS, LIGHT BAR, BLACK |
| 9 | 1 | 1102.00451.00 | QUICK CONNECT SRYHEAD ASSEMBLY 30/40'S, BASIC |
| 10 | 1 | 1024.00063.00 | O-RING, 3 15/16" x 3/32" CS, DASH # 154, BUNA-N, DURO-A50 |
| 11 | 2 | 1024.00107.00 | O-RING, 1 3/16" OD X 1 1/16" ID X 1/16" TH, BYPASS SEAL |
| 12 | 1 | 1023.00343.00 | VENT INSERT, QUICK CONNECT |
| 13 | 2 | 1024.00106.00 | O-RING, 13/16"OD X 11/16"ID X 1/16" TH, FOR QUICK CONNECT |
| 14 | 2 | 1023.00342.00 | QUICK CONNECT CLIP |
| 15 | 9 | 1083.00010.00 | WASHER, #10 SCREW W/NEOPRENE-BONDED SEAL |
| 16 | 9 | 1084.00006.00 | NUT, 8-32 18-8 HEX MACHINE SCREW |
| 17 | 1 | 1086.00004.00 | BUSHING, SNAP, 1" MOUNTING HOLE |
| 18 | 1 | 1024.00098.00 | VENT TUBE, CBS- EXTRACTOR SERIES |
| 19 | 1 | 1102.00243.00 | ADAPTER ASSY, 3/4" BSP x 1/4" NPT x 3/8" TUBE |
| 20 | 2 | 1065.00009.00 | GROUND LUG CONNECTOR, 14-2 AWG, ALUMINUM |
| 21 | 1 | 1044.00012.00 | LABEL GROUND, CE |
| 22 | 12 | 1084.00011.00 | NUT, CLIP ON (J-NUT), #6-32, 22-20 GA., BLK-PH FINISH |
| 23 | 1 | 1025.00058.00 | TUBE, 9/16"OD X 5/16"ID X 25.00"LG |
| 24 | 1 | 1086.00009.00 | CLAMP, 3/4" MAX TUBE OD FLOW CONTROL |
| 25 | 4 | 1086.00003.00 | UNICLAMP, 15.9 HOSE OD CLAMP |
| 26 | 1 | 1112.00531.00 | WELDMENT FRONT COVER, CBS-2240 |
| 27 | 1 | 1001.00413.00 | COVER TOP, CBS-2231/41 |
| 28 | 1 | 1001.00414.00 | COVER, UPPER BASE, CBS-2231/41 |
| 29 | 12 | 1082.00017.00 | SCREW, TRUSS HD. PHIL. MACHINE, # 6-32 X 1/2 LG. |
| 30 | 1 | 1046.00035.00 | LABEL, WARNING "TO REDUCE RISK OF ELECTRIC SHOCK OR FIRE" |
| 31 | 1 | 1046.00003.00 | LABEL, CSD WARNING, 1.5" X 5.0" |
| 32 | 1 | 1041.00033.00 | BLACK EXTRACTOR PLUS LABEL, LASER ENGRAVED |
| 33 | 1 | 1402.00097.10 | WIRE HARNESS, CBS-1240/50, LOW AMP, UNIVERSAL |
| 34 | 1 | 1104.00179.00 | TANK ASSEMBLY, CBS-2241, 2 X 1.5KW/120VAC |
| 34 | 1 | 1104.00178.00 | TANK ASSEMBLY, CBS-2241, 1 X 1.5KW/120VAC |
| 34 | 1 | 1104.00180.00 | TANK ASSEMBLY, CBS-2241, 1 X 1.7KW/120VAC |
| 34 | 1 | 1104.00182.00 | TANK ASSEMBLY, CBS-2241, 1 X 2.3KW/120VAC |
| 34 | 1 | 1104.00184.00 | TANK ASSEMBLY, CBS-2241, 1 X 2.3KW/240VAC |
| 34 | 1 | 1104.00185.00 | TANK ASSEMBLY, CBS-2241, 1 X 3KW/240VAC |
| 35 | 1 | 1402.00039.10 | HARNESS HIGH AMP, CBS-2231/41/51, UL |
| 36 | 1 | 1402.00039.11 | HARNESS ADDITION, HIGH AMP, CBS-2231/41/51, UL |
| 37 | 1 | 1402.00121.10 | WIRE HARNESS ADDITION, HIGH AMP, EMI FILTER, 2-POLE, CE |
| 38 | 1 | B014218BN2BK | BREW BASKET ASSY, BLACK, 13" X 5", 0.218" DIA HOLE, BROWN PLUG |
| 39 | 1 | B003218B1 | BREW BASKET ASSY, 13" X 5", .218 DIA HOLE, BLACK |
| 40 | 1 | 1024.00111.00 | GROMMET, SILICONE, W/ POSITION TABS |
| 41 | 1 | 1023.00362.00 | FITTING VENT, ELBOW, .375" X .375", SELF POSITIONING |
| 42 | 1 | 1013.00130.00 | TUBE, 304SS, .625OD X .065 WALL X 9-1/4" LG. |
| 43 | 1 | 1023.00348.00 | HOT WATER INSERT, MANUAL FAUCET |
| 44 | 1 | 1071.00055.00 | FAUCET, HOT WATER, PSC-BR-8, WITH FLAT AND STEM |
| 45 | 1 | 1084.00048.00 | JAM NUT, 1/2-20 UNF, NICKEL PLATED BRASS |
| 46 | 1 | 1003.00370.00 | HOT WATER INSERT LOCK |
| 47 | 1 | 1025.00120.00 | TUBE, 9/16"OD X 5/16"ID X 13.00"LG |
| 48 | 1 | 1024.00051.00 | GROMMET, SILICONE, BLANK |
| 49 | 1 | 1023.00349.00 | HOT WATER INSERT, NO FAUCET |
| 50 | 1 | 1023.00369.00 | ORIFICE INSERT, QUICK CONNECT, 3/16" HOLE |
| 51 | 1 | 1057.00076.00 | VALVE ASSEMBLY, COMPLETE, NG, DELTROL |
| 52 | 1 | 1023.00344.00 | PLUG INSERT, QUICK CONNECT |
| 53 | 1 | 1029.00042.00 | BYPASS L-TUBE, SILICONE, 2200 SINGLE SERIES |
| 54 | 1 | 1102.00219.00 | ASSEMBLY, BB LOCKER, 24VDC |
| 55 | 1 | 1003.00259.00 | BRACKET, BREW BASKET LOCK COVER |
| 56 | 4 | 1083.00009.00 | WASHER, #6 SCREW, INTL TOOTH LOCKWASHER |
| 57 | 2 | 1084.00010.00 | NUT, HEX, #6-32, UNDERSIZED, ZINC PLATED |
| 58 | 4 | 1073.00002.00 | LEG, FLANGE FOOT, 4.0" HIGH |
| 59 | 1 | 1086.00008.00 | CONNECTOR, CLAMP, NON-METALLIC CABLE, 3/4" |
| 60 | 1 | 1083.00032.00 | WASHER, FLAT, 1.250"OD X 0.835"ID, SS |
| 61 | 1 | 1086.00048.00 | SKINTOP, 1/2" NPT, Ø.157"-.354" CABLE, BLK |
| 62 | 1 | 1086.00049.00 | LOCKNUT, SKINTOP, 1/2" NPT, BLACK HEX |
| 63 | 1 | 1044.00013.00 | LABEL EQUIPOTENTIALITY, CE |
| 64 | 1 | 1052.00029.00 | EMI FILTER, TWO LINE 20A, 120/250VAC |
| 65 | 2 | 1084.00012.00 | NUT, HEX, #6-32 MACHINE SCREW |
| 66 | 1 | 1063.00016.00 | POWER CORD, 120VAC W/NEMA 5-15P PLUG |
| 67 | 1 | 1063.00015.00 | CORD, 120 VAC, 12/3 AWG, 20 AMP, W/5-20P NEMA PLUG |

Parts Diagrams CBS-1242


FETCO CBS-1242
Drawing Number
1101.00579.00



#6 Part Number 1102.00471.00
ELECTRICAL COMPONENT LATTICE


| Ref | Qty | Part Number | Description Drawing 1101.00579.00, CBS-1242 |
|-------|-----|---------------|---|
| 1 | 1 | 1111.00103.00 | WELDMENT BODY, CBS-2242 |
| 2 | 6 | 1084.00051.00 | NUT, HEX LOCKWASHER, #8-32, 18-8 ST. STL. |
| 3 | 1 | 1102.00470.00 | FRONT PANEL ASSY, DOUBLE, PLUS SERIES |
| 4 | 2 | 1082.00029.00 | SCREW, #6 X 3/8 LG, TRUSS HD PHIL, SHEET MTL |
| 5 | 2 | 1082.00058.00 | SCREW, # 8-32 X 5/8, FLAT HD, PH, 18-8 SS |
| 6 REF | 1 | Reference | ELECTRICAL COMPONENT LATTICE, NEXT GEN XV+ |
| 6-1 | 1 | 1023.00350.00 | ELECTRICAL MOUNTING LATTICE, COMMON |
| 6-2 | 1 | 1052.00023.00 | EUROSTRIP HE16 TERM. BLOCK, 4 POLE, 63 AMP, 18-8 AWG |
| 6-3 | 2 | 1082.00056.00 | SCREW, # 8-16 x 1" PAN HD PHIL, THREAD FORMING, FOR PLASTICS, 18-8 SS |
| 6-4 | 2 | 1058.00024.00 | SWITCH, POWER, DOUBLE POLE, 16A, 125/250 VAC |
| 6-5 | 4 | 1057.00043.00 | SOLENOID VALVE, 5.5L/min, 180 DEG, 24VDC |
| 6-6 | 2 | 1082.00010.00 | SCREW, PAN HD. PHIL. MACH., M4x10 ZINC-PLATED |
| 6-7 | 1 | 1052.00059.00 | POWER SUPPLY, 90-264VAC/24VDC, 2.25A |
| 6-8 | 2 | 1082.00020.00 | SCREW, #6 X 5/8, TRUSS HD PHIL, SHEET MTL |
| 6-9 | 2 | 1058.00055.00 | USB CONNECTOR |
| 7 | 1 | 1097.00171.00 | ADHESIVE, RGB LED BAR |
| 8 | 1 | 1023.00390.00 | LENS, LIGHT BAR, BLACK |
| 9 | 2 | 1102.00451.00 | QUICK CONNECT SPRAYHEAD ASSEMBLY, 30/40'S, BASIC |
| 10 | 2 | 1024.00063.00 | O-RING, 3 15/16" x 3/32" CS, DASH # 154, BUNA-N, DURO-A50 |
| 11 | 4 | 1024.00107.00 | O-RING, 1 3/16" OD X 1 1/16" ID X 1/16" TH, BYPASS SEAL |
| 12 | 2 | 1023.00343.00 | VENT INSERT, QUICK CONNECT |
| 13 | 3 | 1024.00106.00 | O-RING, 13/16"OD X 11/16"ID X 1/16" TH, FOR QUICK CONNECT |
| 14 | 4 | 1023.00342.00 | QUICK CONNECT CLIP |
| 15 | 18 | 1083.00010.00 | WASHER, #10 SCREW W/NEOPRENE-BONDED SEAL |
| 16 | 18 | 1084.00006.00 | NUT, 8-32 18-8 HEX MACHINE SCREW |
| 17 | 2 | 1024.00098.00 | VENT TUBE, CBS- EXTRACTOR SERIES |
| 18 | 2 | 1086.00004.00 | BUSHING, SNAP, 1" MOUNTING HOLE |
| 19 | 1 | 1102.00243.00 | ADAPTER ASSY, 3/4" BSP x 1/4" NPT x 3/8" TUBE |
| 20 | 2 | 1065.00009.00 | GROUND LUG CONNECTOR, 14-2 AWG, ALUMINUM |
| 21 | 1 | 1044.00012.00 | LABEL GROUND, CE |
| 22 | 12 | 1084.00011.00 | NUT, CLIP ON (J-NUT), #6-32, 22-20 GA., BLK-PH FINISH |
| 23 | 1 | 1025.00058.00 | TUBE, 9/16"OD X 5/16"ID X 25.00"LG |
| 24 | 1 | 1086.00009.00 | CLAMP, 3/4" MAX TUBE OD FLOW CONTROL |
| 25 | 4 | 1086.00003.00 | UNICLAMP, 15.9 HOSE OD CLAMP |
| 26 | 1 | 1112.00531.00 | WELDMENT FRONT COVER, CBS-2240 |
| 27 | 1 | 1001.00408.00 | COVER TOP, CBS-2232/42 |
| 28 | 1 | 1001.00409.00 | COVER, UPPER BASE, CBS-2232/42 |
| 29 | 12 | 1082.00017.00 | SCREW, TRUSS HD. PHIL. MACHINE, # 6-32 X 1/2 LG. |
| 30 | 1 | 1046.00035.00 | LABEL, WARNING "TO REDUCE RISK OF ELECTRIC SHOCK OR FIRE" |
| 31 | 2 | 1046.00003.00 | LABEL, CSD WARNING, 1.5" X 5.0" |
| 32 | 1 | 1041.00033.00 | BLACK EXTRACTOR PLUS LABEL, LASER ENGRAVED |
| 33 | 1 | 1402.00097.10 | WIRE HARNESS, CBS-1240/50, LOW AMP, UNIVERSAL |
| 34 | 1 | 1402.00098.11 | HARNESS ADDITION, LOW AMP, CBS-1232/42, UL |
| 35 | 1 | 1104.00188.00 | TANK ASSEMBLY, CBS-2242, 2 X 3KW/240VAC |
| 35 | 1 | 1104.00187.00 | TANK ASSEMBLY, CBS-2242, 2 X 2.3KW/240VAC |
| 35 | 1 | 1104.00189.00 | TANK ASSEMBLY, CBS-2242, 2 X 4KW/240VAC |
| 36 | 1 | 1402.00037.10 | HARNESS HIGH AMP, CBS-2232/42/51, UL |
| 37 | 1 | 1402.00121.10 | WIRE HARNESS ADDITION, HIGH AMP, EMI FILTER, 2-POLE, CE |
| 38 | 1 | B014218BN2BK | BREW BASKET ASSY, BLACK, 13" X 5", 0.218" DIA HOLE, BROWN PLUG |
| 39 | 1 | B003218B1 | BREW BASKET ASSY, 13" X 5", .218 DIA HOLE, BLACK |
| 40 | 1 | 1024.00111.00 | GROMMET, SILICONE, W/ POSITION TABS |
| 41 | 1 | 1023.00362.00 | FITTING VENT, ELBOW, .375" X .375", SELF POSITIONING |
| 42 | 1 | 1013.00130.00 | TUBE, 304SS, .625OD X .065 WALL X 9-1/4" LG. |
| 43 | 1 | 1023.00348.00 | HOT WATER INSERT, MANUAL FAUCET |
| 44 | 1 | 1071.00055.00 | FAUCET, HOT WATER, PSC-BR-8, WITH FLAT AND STEM |
| 45 | 1 | 1084.00048.00 | JAM NUT, 1/2-20 UNF, NICKEL PLATED BRASS |
| 46 | 1 | 1003.00370.00 | HOT WATER INSERT LOCK |
| 47 | 1 | 1025.00120.00 | TUBE, 9/16"OD X 5/16"ID X 13.00"LG |
| 48 | 1 | 1024.00051.00 | GROMMET, SILICONE, BLANK |
| 49 | 1 | 1023.00349.00 | HOT WATER INSERT, NO FAUCET |
| 50 | 1 | 1023.00369.00 | ORIFICE INSERT, QUICK CONNECT, 3/16" HOLE |
| 51 | 1 | 1057.00076.00 | VALVE ASSEMBLY, COMPLETE, NG, DELTROL |
| 52 | 1 | 1029.00042.00 | BYPASS L-TUBE, SILICONE, 2200 SINGLE SERIES |
| 53 | 1 | 1023.00344.00 | PLUG INSERT, QUICK CONNECT |
| 54 | 1 | 1102.00219.00 | ASSEMBLY, BB LOCKER, 24VDC |
| 55 | 1 | 1003.00259.00 | BRACKET, BREW BASKET LOCK COVER |
| 56 | 3 | 1083.00009.00 | WASHER, #6 SCREW, INTL TOOTH LOCKWASHER |
| 57 | 1 | 1084.00010.00 | NUT, HEX, #6-32, UNDERSIZED, ZINC PLATED |
| 58 | 3 | 1073.00002.00 | LEG, FLANGE FOOT, 4.0" HIGH |
| 59 | 1 | 1086.00008.00 | CONNECTOR, CLAMP, NON-METALLIC CABLE, 3/4" |
| 60 | 1 | 1086.00031.00 | SKINTOP, 3/4" NPT, 0.354" - 0.630" DIA CABLE, BLK |
| 61 | 1 | 1086.00032.00 | LOCKNUT, SKINTOP, 3/4" NPT, BLACK HEX |
| 62 | 1 | 1044.00013.00 | LABEL EQUIPOTENTIALITY, CE |
| 63 | 1 | 1052.00027.00 | EMI FILTER, THREE LINE 30A, 250/440VAC |
| 64 | 2 | 1084.00012.00 | NUT, HEX, #6-32 MACHINE SCREW |
| 65 | 1 | 1112.00246.00 | WELDMENT BRACKET TERMINAL BLOCK, 3 POLE |
| 66 | 1 | 1052.00022.00 | EUROSTRIP HE10 TERM. BLOCK, 3 POLE, 50AMP, 18-8 AWG |
| 67 | 2 | 1082.00082.00 | SCREW, PHILLIP HD., 8-32 THREAD |

CBS-1241 Tank Assembly



TANK ASSY, CBS-1241 Single Heater Drawing number 1104.000178.00, 1104.000180.00, 1104.000182.00, 1104.000184.00, 1104.000185.00, 1104.000186.00


| REF | QTY | Part number | Description |
|-----|-----|----------------------|---|
| 1 | 1 | 1114.00170.00 | WELDMNT, TANK, CBS-2241 |
| 2 | 1 | 1024.00114.00 | TANK GASKET - NG HEATER PLATE, TWO ELEMENT |
| 3 | 1 | 1114.00184.00 | WELDMNT TANK HEATER BRACKET, NG-2231, SINGLE |
| 4 | 2 | 1024.00053.00 | LEVEL AND TEMP PROBE GROMMET |
| 5 | 3 | 1024.00050.00 | GROMMET, SILICONE, 11.4mm ID |
| 6 | 1 | 1053.00052.00 | THERMOSTAT, SINGLE SHOT, SCREW CONNECTIONS, 240V/25A, |
| 7 | 8 | 1083.00009.00 | WASHER, #6 SCREW , INTL TOOTH LOCKWASHER |
| 8 | 8 | 1084.00010.00 | NUT, HEX, #6-32, UNDERSIZED, ZINC PLATED |
| 9 | 1 | 1107.00030.00 | HEATER ASSEMBLY, IMMERSION 1500W/120VAC |
| 9 | 1 | 1107.00031.00 | HEATER ASSEMBLY, IMMERSION 1700W/120VAC |
| 9 | 1 | 1107.00029.00 | HEATER ASSEMBLY, IMMERSION 2300W/120VAC |
| 9 | 1 | 1107.00037.00 | HEATER ASSEMBLY, IMMERSION 2300W/240VAC |
| 9 | 1 | 1107.00005.00 | HEATER ASSEMBLY,IMMERSION, 3000W, 240VAC |
| 9 | 1 | 1107.00010.00 | HEATER ASSEMBLY, IMMERSION 4000W/240VAC |
| 10 | 1 | 1003.00140.00 | ALUMINUM BRACKET FOR SSR |
| 11 | 1 | 1052.00033.00 | RELAY, SOLID STATE, 50A/480VAC, W/BUILD IN VARISTOR |
| 12 | 2 | 1081.00042.00 | STANDOFF, 1/4" HEX |
| 13 | 1 | 1112.00019.00 | PROBE WELDMNT, WATER LEVEL 2.600" LG |
| 14 | 1 | 1102.00161.00 | PROBE ASSEMBLY, TEMP. AND LLC, 8" LONG |
| 15 | 1 | 1023.00168.00 | FITTING, STRAIGHT, GROMMET, .400" |
| 16 | 1 | 1023.00166.00 | FITTING, COLD WATER INLET, GROMMET DESIGN |
| 17 | 1 | 1044.00004.00 | LABEL, DANGER, HIGH VOLTAGE |
| 18 | 1 | 1024.00051.00 | GROMMET, SILICONE, BLANK |
| 19 | 1 | 1023.00212.00 | FITTING, ELBOW, GROMMET, .500" |
| 20 | 1 | 1022.00115.00 | TANK INSULATION, CBS-2241 |
| 21 | 2 | 1082.00136.00 | BRASS SCREW, #8-32 X 1/4", PHILLIPS PAN HEAD |



TANK ASSY, CBS-1241 Two Heater Drawing number 1104.000181.00 and 1104.000183.00

| REF | QTY | Part number | Description |
|-----|-----|---------------|---|
| 1 | 1 | 1114.00170.00 | WELDMENT, TANK, CBS-2241 |
| 2 | 1 | 1024.00114.00 | TANK GASKET - NG HEATER PLATE, TWO ELEMENT |
| 3 | 1 | 1114.00176.00 | WELDMENT TANK HEATER BRACKET, NG-2231 |
| 4 | 2 | 1024.00053.00 | LEVEL AND TEMP PROBE GROMMET |
| 5 | 3 | 1024.00050.00 | GROMMET, SILICONE, 11.4mm ID |
| 6 | 2 | 1053.00052.00 | THERMOSTAT, SINGLE SHOT, SCREW CONNECTIONS, 240V/25A, |
| 7 | 10 | 1083.00009.00 | WASHER, #6 SCREW , INTL TOOTH LOCKWASHER |
| 8 | 10 | 1084.00010.00 | NUT, HEX, #6-32, UNDERSIZED, ZINC PLATED |
| 9 | 2 | 1107.00031.00 | HEATER ASSEMBLY, IMMERSION 1700W/120VAC |
| 9 | 2 | 1107.00029.00 | HEATER ASSEMBLY, IMMERSION 2300W/120VAC |
| 10 | 2 | 1003.00140.00 | ALUMINUM BRACKET FOR SSR |
| 11 | 2 | 1052.00033.00 | RELAY, SOLID STATE, 50A/480VAC, W/BUILD IN VARISTOR |
| 12 | 4 | 1081.00042.00 | STANDOFF, 1/4" HEX |
| 13 | 1 | 1112.00019.00 | PROBE WELDMENT, WATER LEVEL 2.600" LG |
| 14 | 1 | 1102.00161.00 | PROBE ASSEMBLY, TEMP. AND LLC, 8" LONG |
| 15 | 1 | 1023.00168.00 | FITTING, STRAIGHT, GROMMET, .400" |
| 16 | 1 | 1023.00166.00 | FITTING, COLD WATER INLET, GROMMET DESIGN |
| 17 | 1 | 1044.00004.00 | LABEL, DANGER, HIGH VOLTAGE |
| 18 | 1 | 1023.00212.00 | FITTING, ELBOW, GROMMET, .500" |
| 19 | 1 | 1024.00051.00 | GROMMET, SILICONE, BLANK |
| 20 | 1 | 1022.00115.00 | TANK INSULATION, CBS-2241 |
| 21 | 4 | 1082.00136.00 | BRASS SCREW, #8-32 X 1/4", PHILLIPS PAN HEAD |


CBS-1242 Tank Assembly



CBS-1242 Hot Water Tank Drawing 1104.00188;.00; 1104.00187.00, 1104.00189.00


| Ref# | Qty | Part number | Description |
|-----------|----------|---------------|--|
| 1 | 1 | 1114.00171.00 | WELDMENT TANK NG-2242, GROMMET DESIGN |
| 2 | 2 | 1024.00115.00 | TANK GASKET - NG HEATER PLATE, ONE ELEMENT |
| 3 | 2 | 1114.00181.00 | WELDMENT TANK HEATER BRACKET, NG-SMALL, ONE HEATER |
| 4 | 2 | 1024.00053.00 | LEVEL AND TEMP PROBE GROMMET |
| 5 | 5 | 1024.00050.00 | GROMMET, SILICONE, 11.4mm ID |
| 6 | 1 | 1112.00019.00 | PROBE WELDMENT, WATER LEVEL 2.600" LG |
| 7 | 1 | 1102.00161.00 | PROBE ASSEMBLY, TEMP. AND LLC, 8" LONG |
| 8 | 1 | 1023.00212.00 | FITTING, ELBOW, GROMMET, .500" |
| 9 | 2 | 1023.00203.00 | FITTING, STRAIGHT, GROMMET, .625" |
| 10 | 1 | 1023.00166.00 | FITTING, COLD WATER INLET, GROMMET DESIGN |
| 11 | 2 | 1107.00037.00 | HEATER ASSEMBLY, IMMERSION 2300W/240VAC |
| 11 | 2 | 1107.00005.00 | HEATER ASSEMBLY, IMMERSION, 3000W, 240VAC |
| 11 | 2 | 1107.00010.00 | HEATER ASSEMBLY, IMMERSION 4kW/240VAC |
| 12 | 2 | 1053.00052.00 | THERMOSTAT, SINGLE SHOT, SCREW CONNECTIONS, 240V/25A |
| 13 | 12 | 1083.00009.00 | WASHER, #6 SCREW , INTL TOOTH LOCKWASHER |
| 14 | 12 | 1084.00010.00 | NUT, HEX, #6-32, UNDERSIZED, ZINC PLATED |
| 15 | 1 | 1003.00140.00 | ALUMINUM BRACKET FOR SSR |
| 16 | 1 | 1052.00033.00 | RELAY, SOLID STATE, 50A/480VAC, W/BUILD IN VARISTOR |
| 17 | 2 | 1081.00042.00 | STANDOFF, 1/4" HEX |
| 18 | 1 | 1044.00004.00 | LABEL, DANGER, HIGH VOLTAGE |
| 19 | 1 | 1022.00066.00 | TANK INSULATION FRONT, CBS-2142 |
| 20 | 1 | 1022.00067.00 | TANK INSULATION BACK, CBS-2142 |
| 21 | 4 | 1082.00136.00 | BRASS SCREW, #8-32 X 1/4", PHILLIPS PAN HEAD |
| 12 | 2 | 1053.00052.00 | THERMOSTAT, SINGLE SHOT, SCREW CONNECTIONS, 240V/25A |
| 13 | 12 | 1083.00009.00 | WASHER, #6 SCREW , INTL TOOTH LOCKWASHER |

Small Spray Assembly Parts



| Ref# | Qty | Part number | Description |
|------|-----|---------------|--|
| 1 | 1 | 1023.00352.00 | BASE, QUICK CONNECT SPRAY HEAD, 30/40'S |
| 2 | 1 | 1024.00063.00 | O-RING, 3 15/16" x 3/32" CS, DASH # 154, BUNA-N, DURO-A50 |
| 3 | 2 | 1024.00107.00 | O-RING, 1 3/16" OD X 1 1/16" ID X 1/16" TH, BYPASS SEAL |
| 4 | 1 | 1102.00113.00 | SWITCH, REED, ASSEMBLY |
| 5 | 1 | 1102.00479.00 | ASSEMBLY, CASCADE SPRAY DOME, NEXT GEN, ORANGE |
| 6 | 2 | 1057.00076.00 | VALVE ASSEMBLY, COMPLETE, NG, DELTROL (interchangeable with 1057.00078.00) |
| 6 | 2 | 1057.00078.00 | VALVE ASSEMBLY, COMPLETE, NG, RPE (interchangeable with 1057.00076.00) |
| 7 | 3 | 1023.00342.00 | QUICK CONNECT CLIP |
| 8 | 1 | 1023.00343.00 | VENT INSERT, QUICK CONNECT |
| 9 | 2 | 1024.00106.00 | O-RING, 13/16"OD X 11/16"ID X 1/16" TH, FOR QUICK CONNECT |
| 10 | 1 | 1024.00098.00 | VENT TUBE, CBS- EXTRACTOR SERIES |
| 11 | 1 | 1023.00369.00 | ORIFICE INSERT, QUICK CONNECT, 3/16" HOLE |
| 12 | 1 | 1023.00344.00 | PLUG INSERT, QUICK CONNECT |

Wiring Diagrams




SKU E1231US-1X117 Domestic-Dual Voltage Brewer is supplied by factory as 120VAC

For 208 -240 volt application: connect L1, N and L2

SKU: E1241US-1X117-PM001
CBS-1241 Domestic-Dual Voltage

Wiring diagram 1401.00190.10 CBS-1241PLUS
 SKU E1241US-1A115-PM001; E1241US-1A123-PM002;
 E1241IN-1B123-PM000; E1241IN-1B130-PM000;
 E1241IN-1B140-PM000;

1PH
 100-120VAC
 OR
 (200-240VAC)




POWER TERMINAL
 50A/600VAC

DWG. NAME:
 WIRING, CBS-1231/41, 1 HEATER, (L1, N(L2) + GND),
 100-120VAC OR 200-240VAC, U.L.
 DRAWING NO. 1401.00190.10

FETCO
 FOOD EQUIPMENT TECHNOLOGY COMPANY
 600 ROSE RD.
 LAKE ZURICH, IL 60047
 PHONE: 847-719-3000 FAX: 847-719-3001
 WWW.FETCO.COM

Wiring diagram 1401.00196.10 CBS-1242 PLUS
 SKU E1242US-1B223-PM000; E1242US-1B230-PM000;
 E1242IN-1B223-PM000; E1242IN-1B230-PM000; E1242NM-1B230-PM000



FETCO
 FOOD EQUIPMENT TECHNOLOGY COMPANY
 6015 S. STATE ST. SUITE 200
 LAKE ZURICH, IL 60047
 PHONE: 847-719-3000, FAX: 847-719-3011
 WWW.FETCO.COM

DWG. NAME:
 WIRING, CBS-1200-PLUS, 2 HEATERS,
 (L1, L2(N) + GND), 200-240VAC, UL,
 DRAWING No. 1401.00196.10