



1
Select a coffee dispenser and make sure that it is empty before starting a brew cycle.



5
When the brew cycle is complete the stop button will go dark and the brew light will continue to flash for an additional timed cycle. This indicates the brewer is now in the drip delay. **DO NOT REMOVE BREW BASKET** HOT COFFEE MAY STILL BE FLOWING OUT OF THE BREW BASKET.



2
3
Make sure the dispensers cover plug is in the opened position.



6
After the brew light stops flashing and you have verified that coffee is no longer flowing from the brew basket, you may remove the brew basket and dispose of the spent filter and coffee grounds.



7
8
Place L3S-10 coffee server onto brew stand, making sure to line up server feet with the holes in the brew stand.

Move server to the dedicated serving area.



4
9
Select the desired batch button and push and hold for two seconds. The stop button will illuminate and the batch button will begin to flash. This indicates that the brew cycle has begun.



10
To help provide for maximum hold and serving time please make sure that the dispenser cover plug is in the closed position.

FETCO®

Coffee Brewer Operating Instructions



CBS-2032ee with LUXUS® L3S-10

