



CARING FOR YOUR LUXUS® THERMAL DISPENSER

Before cleaning, be sure that all residual coffee in the dispenser has been emptied out. Next, fill the dispenser 1/4 to 1/2 full with hot water. If desired, an appropriate cleaning solution may also be used.

Daily Cleaning:



First, remove the black funnel assembly. Then, using a cleaning brush, scrub out the liner thoroughly, loosening coffee oils into the water.



Remove the drip tray by depressing the button on the back of the dispenser while pulling forward on the front of the drip tray. Discard any coffee from the tray. Clean and rinse the drip tray before replacing. Empty out the dirty water through the faucet.

CAUTION: Never immerse the dispenser or funnel completely in water or run through any dishwasher.

Weekly Cleaning:



Remove the faucet guard by unscrewing the lock nut under the dispenser. Then lift up on the grey knob under the faucet and turn the faucet 180 degrees. Pull forward to remove the faucet. Using a small brush clean the dispense tube and faucet.