

## CARING FOR YOUR LUXUS<sup>®</sup> THERMAL DISPENSER

Before cleaning, be sure that all residual coffee in the dispenser has been emptied out. Next, fill the dispenser 1/4 to 1/2 full with hot water. If desired, an appropriate cleaning solution may also be used.

### Daily Cleaning:




First, remove the black funnel assembly. Then, using a cleaning brush, scrub out the liner thoroughly, loosening coffee oils into the water.



Empty out the dirty water, either through the faucet or simply by tipping the dispenser over and dumping out through the top opening.

**CAUTION: Never immerse the dispenser completely in water or run through any dishwasher.**

### Weekly Cleaning:



Remove sight gauge tube and clean with water and/or cleaning solution, using the small brush included with the dispenser.



Unscrew the faucet and remove the rubber seat cup. Clean using the small brush included with the dispenser.