

FETCO[®]

CORPORATION

COFFEE BREWING OPERATING INSTRUCTIONS



Before starting the initial brew, pre-heating of the LUXUS[®] Thermal Dispenser(s) is strongly recommended to avoid brewing into a cold or room temperature container -- thereby accelerating heat loss. This can be done either at night during cleanup or first thing in the morning.



Make sure that "Ready" lamp is on, brew basket(s) are in place, and the LUXUS[®] Thermal Dispenser is in position under the brew basket.



Rotate the brew handle clockwise to the brew position (the handle will automatically stay down). When the hot water brew finishes, let the water stay in the inside the container for about 5 - 10 minutes. Drain the water from the container before beginning to brew.



Place a paper filter carefully inside the brew basket and then fill it with the appropriate amount of coffee.



Slide the brew basket all the way back along its tracks, being sure to lift the Safety-Latch in order to position the brew basket all the way back.



Make sure the LUXUS[®] Thermal Dispenser is empty, in position under the brew head, and the faucet is closed. Rotate the brew handle to the "Brew" position. When the brew is completed the handle will pop back up, and you now have fresh brewed, ready-to-serve coffee.