



CARING FOR YOUR FETCO

THERMAL DISPENSER



IMPORTANT: DO NOT overfill or submerge dispenser in water.
DO NOT submerge the funnel assembly in water.
Damage caused by doing this will void the factory warranty.



-Remove the digital funnel assembly from the dispenser. With normal cleaning, the funnel will operate properly for many years.

-Wipe the funnel with a damp cloth of warm soapy water.

NOTE: DO NOT SUBMERGE the funnel assembly in water or any other liquid.

-Makes sure the gold contacts on the funnel are clean. If there is coffee buildup on the funnel contacts, use vinegar to clean them.

-Avoid using very abrasive products to clean the gold funnel contacts, as this may damage the funnel.

-Before cleaning dispenser, be sure that all of the residual coffee in the dispenser has been emptied out.

-Fill the dispenser 3/4 full with very hot water. **DO NOT overfill or submerge the dispenser.**

-Add a food-safe cleaning solution like Urnex or Scale Kleen which should be used according to the packet instructions. Let solution work for 1-2 hours and then rinse with warm water and sanitize.

-Do not use any stainless steel polishes or cleaners on any plastic parts, this will cause the plastic to prematurely fail, which will not be covered under warranty.

-Do not use abrasive cleaners, brushes or scouring pads that will damage the stainless steel and / or the plastic parts.

CARING FOR YOUR FETCO THERMAL DISPENSER

(continued)



IMPORTANT: DO NOT use any stainless steel polishes or cleaners on any plastic parts, this will cause the plastic to prematurely fail, which will not be covered under warranty.

DO NOT use abrasive cleaners, brushes or scouring pads that will damage the plastic parts.



-Remove the drip tray by depressing the button on the back of the dispenser while pulling forward on the front of the drip tray.

-Discard any coffee from the tray. Clean the tray and stand with warm soapy water and rinse the drip tray before replacing.



-Empty out the dirty water through the faucet.

-Remove the faucet guard by unscrewing the lock nut under the dispenser. Clean with warm soapy water and then rinse thoroughly.



-Lift up on the grey knob under the faucet and turn the faucet 180 degrees. Then pull forward to remove the faucet.

-Using a small brush clean the dispense tube and faucet. Rinse and reinstall the faucet.