## INSTRUCTION SHEET



Subject: Control Board Replacements-2000e Series Date:

Applies to: All CBS-2000e & 2000s Series Coffee Brewers

May 3, 2010 Rev-001

These instructions apply to the following models:

CBS-2031e CBS-2031s CBS-2041e CBS-2051e CBS-2032e CBS-2032s CBS-2042e CBS-2052e

## Installation

Due to variations in the front panels and control boards on 2000e Series coffee brewers. the control board may occasionally be positioned too close to the plastic overlay. This may cause excessive pressure on the buttons, causing them to stick and generating error code 255.

As a solution to prevent this problem, we use small nylon washers as spacers on the posts to which the control boards are mounted.

All control boards that are sent out as replacement parts include a supply of these washers. Six washers are required for single brewers, seven for dual brewers.

When installing a replacement control board with washers, place one washer on each mounting post as shown in the drawing. If the brewer already has washers on the posts, it is not necessary to install additional washers.

## **Programming**

After installing this board, the brewer's programming must be set to the correct model number or the brewer may not function properly. See Programming Instructions; address #56 in the brewers User's Guide. User's Guide can be down loaded from our web site at www.fetco.com click on Technical Support then User's Guides and select the appropriate Guide.

PART # 1024.00021.00 WASHER, NYLON

P163 Revised: April 13,2017